


PROGEAR ROMs		B-board		EPROM type
1.bin	audio PRG (Z80)	1	1A	27C010
3u.bin	main PRG (68K)	3	6A	27C4096
4u.bin		4	7A	
11.bin	sound data	11	1E	27C322
12.bin		12	2E	
13.bin	GFX	13	1J	
15.bin		15	3J	
17.bin		17	1M	
19.bin		19	3M	

### Configuration des jumpers du B-board CPS-2

<b>ON</b>	JP1	JP4	JP5	JP9	JP11	JP13	JP14	JP16	JP18	JP20	JP22	JP24	JP26	JP28
<b>OFF</b>	JP2	JP3	JP6	JP8	JP10	JP12	JP15	JP17	JP19	JP21	JP23	JP25	JP27	JP29



17/02/2011

**RGBay**

**CAPCOM** Play System 2 (a.k.a. CPS-2) cartmodding

A4

[http:// RETROGAMEBAY.free.fr](http://RETROGAMEBAY.free.fr)